

Resetting the MOTU 828mk3 to the Default State:

Carefully remove the plastic guard from the front panel.

Push the PARAM knob until "828mk3 Setup" appears briefly followed by "LCD Contrast".

Turn the PARAM knob until "Factory Defaults" appears.

Push the VALUE knob to restore the 828mk3 hardware to its factory default settings.

Push the VALUE knob again to confirm, or turn PARAM to cancel.

Carefully replace the plastic guard.

See 828 equipment manual page 44.

Resetting the MOTU 828mkII: (our backup unit when the 828mk3 breaks)

Disconnect Firewire.

Press the Setup knob until the LCD screen reads, "Clock Source".

Turn the Setup knob all the way to the right.

The LCD screen will read, "Factory Defaults Press [SELECT]".

Press the Select knob.

The LCD screen will read, "Are you sure? Push VAL for Yes".

Press Value knob to confirm.

The clock LED will flash when reset is complete.